

- 1. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS AND **INSTALLATION VIDEO**
- 2. REFER TO PRODUCT DATA SHEETS ON WEBSITE FOR FURTHER **INFORMATION**
- 3. PRIME MASONRY CHIMNEY WITH PERM-A-BARRIER® WB PRIMER AS NECESSARY
- 4. RIPCORD® HAS BEEN REMOVED ALONG ROOF AND CHIMNEY FOR EASE OF INSTALLATION

- 5. INSTALL GCP UNDERLAYMENT IN ORDER AS SHOWN BY NUMBERS
- 6. INTEGRATE GCP ROOF DETAIL MEMBRANE AND UNDERLAYMENT TO FORM WATER-SHEDDING LAPS, AND EXTEND FROM EAVE TO BELOW CHIMNEY AND FROM ABOVE CHIMNEY TO RIDGE
- 7. REFER TO NRCA OR SMACNA FOR METAL COUNTERFLASHING AND **ROOFING OPTIONS AT CHIMNEY**
- 8. FOR WOODEN CHIMNEY, REFER TO DETAILS IWSDET-105 AND IWSDET-106



CHIMNEY

GCP ROOF DETAIL MEMBRANE

Drawing: RDMDET-105

Scale: Not to scale

Effective Date: 01/22/18

Supersedes: 02/20/07