



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT LITERATURE
- B. APPLY VYCOR DECK PROTECTOR ONTO PRESSURE TREATED WOOD WHEREVER GALVANIZED CONNECTORS WOULD COME INTO CONTACT WITH PRESSURE TREATED WOOD
- C. FASTEN GALVANIZED CONNECTOR PER MANUFACTURER GUIDELINES AND USE APPROPRIATE HOT-DIPPED GALVANIZED FASTENERS PER ASTM A153
- D. ALL EXPOSED VYCOR SHOULD BE TRIMMED FLUSH TO GALVANIZED CONNECTOR TO PREVENT UV EXPOSURE
- E. VYCOR DOES NOT NEED TO BE TRIMMED IF COVERED WITH DECORATIVE TRIM OR OTHER APPROPRIATE MATERIAL



CORROSION RESISTANCE FOR GALVANIZED CONNECTORS AT COLUMN/POST BASE

VYCOR® DECK PROTECTOR® SELF-ADHERED FLASHING | Supersedes: 09/01/05

Drawing: VCRDET-302

Scale: Not to Scale

Effective Date: 01/31/07