



- NOTES:
- DO NOT PENETRATE OR DAMAGE THE PREPRUFE® DURING CONCRETE PLACEMENT, FORMWORK & BULKHEAD ERECTION AND BETWEEN CONSTRUCTION PHASES
 - EXTEND THE PREPRUFE® A MINIMUM OF 12 IN (300 mm) PAST ANY STEEL EXTENDING FROM THE SLAB
 - REMOVE PROTECTION COURSE AND TEMPORARY FASTENERS JUST PRIOR TO TIE-IN TO NEW PREPRUFE® MEMBRANE
 - ENSURE ANY FASTENER HOLES IN THE MEMBRANE ARE SEALED WITH PREPRUFE® TAPE
 - GCP HYDRODUCT® NOT SHOWN FOR CLARITY
 - GCP MAY REQUIRE AN ALTERNATE GCP WATERSTOP BASED ON DESIGN CONDITIONS

TEMPORARY PROTECTION DURING CONSTRUCTION SEQUENCING

PREPRUFE® WATERPROOFING SYSTEM

DRAWING: PRE-060

SCALE: NOT TO SCALE

EFFECTIVE DATE: 08-01-2025

SUPERCEDES: 10-10-2024