

TB-0112 — Pervious Concrete — Placing, Consolidation and Curing Technical Bulletin

Placing

Pervious concrete pavement may be placed in either a fixed form or slip-form paver. Place the concrete from the truck discharge chute near its final position in order to minimize raking and shoveling. Pumping is not recommended due to the zero or low-slump concrete mix. Since pervious concrete has little water in the mix, it should be placed as quickly as possible. While the fresh concrete waits to discharge, it will be hydrating, using valuable water needed for the placing and curing stages. If a fixed form is used, place the concrete approximately 12 mm (½ in.) higher than the required final elevation with the use of risers along the forms. After depositing the concrete, quickly bring it to the correct elevation with a rake or other hand straight edge tool. Vibratory screeds are acceptable and encouraged.

Caution should be taken to minimize pulling or shoveling the concrete into position, filling the voids or walking on the pervious concrete.

Consolidating

Immediately after striking off, the riser strips should be removed from the forms and the fresh concrete consolidated with a manually operated roller to provide a strong bond between the paste and coarse aggregate, and provide a smooth surface. A minimum pressure of 0.007 Mpa (10 psi) should be used, although care should be taken as excessive pressure may cause the voids to collapse. The surface of pervious concrete should not be closed or sealed. Jointing should take place right after consolidation with a rolling joint tool. Saw cutting, although not recommended, should take place as soon as the pavement is hardened sufficiently to prevent damage.

Curing

Due to the large void content and open pore structure of pervious concrete, drying can more readily occur. Improper curing can lead to raveling (drying and delamination) of the concrete surface.

Therefore curing is critical and should begin immediately (within 20 minutes) after the consolidation phase. If the surface has lost its “sheen”, a light water mist should be used. Polyethylene sheets of 0.15 mm (6 mil) or thicker should be used. Burlap or other woven materials should not be used, as they will not hold the moisture in the concrete. The polyethylene sheet should cover all exposed surfaces and weighted down so it does not blow away. The sheets should remain for a minimum of 7 days for straight cement mixes or 10 days for mixes that contain supplementary cementitious materials. There should not be traffic of any kind on the concrete until the curing period is complete.

Information for this Technical Bulletin on pervious concrete is based on field experience, and was obtained from ACI 522R-06 Pervious Concrete, Design and Control of Concrete Mixtures 2002 by PCA, Pervious Concrete Pavements 2004 by PCA and NRMCA Concrete in Practice CIP 38 Pervious Concrete 2004. For more detailed information please see these publications.

gcpat.com | North America Customer Service: +1 (877) 423 6491

We hope the information here will be helpful. It is based on data and knowledge considered to be true and accurate and is offered for consideration, investigation and verification by the user, but we do not warrant the results to be obtained. Please read all statements, recommendations and suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us. No statement, recommendation, or suggestion is intended for any use that would infringe any patent, copyright, or other third party right.

STRUX is a trademark, which may be registered in the United States and/or other countries, of GCP Applied Technologies Inc. This trademark list has been compiled using available published information as of the publication date and may not accurately reflect current trademark ownership or status.

© Copyright 2018 GCP Applied Technologies Inc. All rights reserved.

In Canada, 294 Clements Road, West, Ajax, Ontario, Canada L1S 3C6.

GCP Applied Technologies Inc., 2325 Lakeview Parkway, Suite 400, Alpharetta, GA 30009, USA

GCP Canada, Inc., 294 Clements Road, West, Ajax, Ontario, Canada L1S 3C6

This document is only current as of the last updated date stated below and is valid only for use in the United States. It is important that you always refer to the currently available information at the URL below to provide the most current product information at the time of use. Additional literature such as Contractor Manuals, Technical Bulletins, Detail Drawings and detailing recommendations and other relevant documents are also available on www.gcpat.com. Information found on other websites must not be relied upon, as they may not be up-to-date or applicable to the conditions in your location and we do not accept any responsibility for their content. If there are any conflicts or if you need more information, please contact GCP Customer Service.

Last Updated: 2023-06-28

gcpat.com/solutions/products/tb-0112-pervious-concrete-placing-consolidation-and-curing-technical-bulletin