



NOTES: - INSTALL PREPRUFE® MEMBRANE AND TAPE IN ORDER AS SHOWN BY NUMBERS  
 - DETAIL ALSO APPLICABLE FOR PREPRUFE PLUS



**END LAP DETAIL FOR WALL OR SLAB - OPTION 2**  
**TAPE APPLIED BEFORE INSTALLATION OF 2ND SIDE LAP**  
**PREPRUFE® WATERPROOFING SYSTEM**

DRAWING: PRE 032

SCALE: Not to scale

EFFECTIVE DATE: 07/01/2016

SUPERCEDES: 03012015

# End Lap Detail for Wall or Slab Option-2



Tape applied after installation of the side laps  
Prior to Membrane Installation, Review the Preprufe®  
Data Sheet

## Surface Prep

All surfaces must be sound and solid to eliminate movement during the concrete pour. Substrate must be regular and smooth with no gaps or voids greater than 0.5 in, 15 mm. The surface should also be free from loose aggregate and sharp protrusions as outlined in the Preprufe® Data Sheet section on Surface Preparation.

## Detailing

1. Apply Hydroduct® according to Hydroduct Data Sheet.
2. Install Preprufe Membrane and Preprufe Tape in order as shown by numbers
3. Overlap the ends of the membrane a minimum of 3 in (75 mm) and remove release liner from both membranes.
4. Apply Preprufe Tape over the end lap as shown and roll firmly.
5. Apply tape a minimum of 2 in (50 mm) beyond all edges of membrane that are not sealed by the selvedge.
6. Remove release liner from tape and discard.

## Special Notes

Preprufe membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.