



TOP TERMINATION AND END LAP

PREPRUFE[®] WATERPROOFING SYSTEM

DRAWING: PRE 048

SCALE: Not to scale

EFFECTIVE DATE: 07/01/2016

SUPERCEDES: 04012015

Top Termination and End Lap

Prior to Membrane Installation, Review the Preprufe®
Data Sheet



Surface Prep

All surfaces must be sound and solid to eliminate movement during the concrete pour. Substrate must be regular and smooth with no gaps or voids greater than 0.5 in (15 mm). The surface should also be free from loose aggregate and sharp protrusions as outlined in the Preprufe® Data Sheet section on Surface Preparation.

Detailing

1. Apply Preprufe field membrane according to standard installation procedures.
2. Apply termination bar to Preprufe membrane.
3. Center Preprufe CJ Tape to cover termination bar and roll firmly.
4. Protect top of termination of membrane from exposure.
5. For end lap, overlap successive membrane rolls by 3 in (75 mm).
6. Apply Preprufe Tape, centered over the lap. (Refer to PRE 031 and PRE 032)
7. Apply Hydroduct® according to Hydroduct Data Sheet.

Special Notes

Preprufe membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.