



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. REMOVE RIPCORD® FROM VYCOR PLUS FOR EASE OF INSTALLATION
- C. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN WITH WEATHER RESISTIVE BARRIER
- D. FOR CONCRETE, MASONRY OR WHERE ADHESION IS MARGINAL, USE PERM-A-BARRIER® WB PRIMER TO PROMOTE VYCOR ADHESION
- E. CHECK LOCAL BUILDING CODES FOR WEATHER RESISTIVE BARRIER REQUIREMENTS AND INSTALL VYCOR PLUS WITH WEATHER RESISTIVE BARRIER TO FORM WATER-SHEDDING LAPS
- F. INSTALL WINDOW PER MANUFACTURER'S RECOMMENDATION AND USE APPROPRIATE SEALANT FOR WINDOW AND WOOD BUCK
- G. DETAIL ALSO RELEVANT FOR VYCOR V40 AND VYCOR BUTYL