



NOTE: - FOR JOINT WHERE MOVEMENT IS EXPECTED (ACTIVE JOINTS) SEE EXPANSION JOINT COVER DETAIL PRO 025.



PASSIVE JOINT COVER

PROCOR[®] WATERPROOFING SYSTEM

DRAWING: PRO 023

SCALE: Not to scale

EFFECTIVE DATE: 07/01/2016

SUPERCEDES: 04012015

Passive Joint Cover

Prior to Membrane Installation, Review the Procor® Data Sheet



Surface Prep

All surfaces must be structurally sound and free from spalled areas, loose aggregate, sharp protrusions or other matter that may hinder the adhesion or regularity of the membrane installation. The surface should also be free from frost, dirt, grease, oil or other contaminants as outlined in the Procor® Data Sheet section on Surface Preparation. Clean loose dust and dirt from the surface.

Detailing

1. Install backer rod and Bituthene® Liquid Membrane or appropriate sealant in passive joint.
2. Install a pretreatment of 60-mil (1.5 mm) of Procor over the passive joint or crack.
3. Install the field membrane in accordance with the Procor Data Sheet section on Installation.
4. Apply Hydroduct 660 according to Hydroduct 660 Data Sheet.

Special Notes

Procor membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation. It is acceptable to apply Procor directly over freshly applied Bituthene Liquid Membrane (LM) provided the LM does not displace.