



DRAIN

PROCOR® WATERPROOFING SYSTEM

DRAWING: PRO030

SCALE: Not to scale

EFFECTIVE DATE: 07/01/2016

SUPERCEDES: 04012015

Drain

Prior to Membrane Installation, Review the Procor® Data Sheet



Surface Prep

All surfaces must be structurally sound and free from spalled areas, loose aggregate, sharp protrusions or other matter that may hinder the adhesion or regularity of the membrane installation. The surface should also be free from frost, dirt, grease, oil or other contaminants as outlined in the Procor® Data Sheet section on Surface Preparation. Clean loose dust and dirt from the surface.

Detailing

1. Ensure that the drain flange (by others) is properly installed before membrane application.
2. Clean drain flange thoroughly.
3. Install a pre-treatment layer of 60-mil (1.5 mm) of Bituthene® Liquid membrane to the flange, extending onto the deck.
4. Within 1 hour of applying the Liquid Membrane, apply 60-mil (1.5 mm) of Procor from edge of drain opening onto the field, completely covering the LM.
5. Install the field membrane in accordance with the Procor Data Sheet section on Installation.
6. Apply clamping ring in a bead of Bituthene Liquid Membrane.
7. Apply Hydroduct 660 according to Hydroduct 660 Data Sheet.

Special Notes

Procor membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation. It is acceptable to apply Procor directly over freshly applied Bituthene Liquid Membrane (LM) provided the LM does not displace.