



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS AND INSTALLATION VIDEO
- B. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
- C. THE DRIP EDGE IS INSTALLED OVER THE FIRST LAYER OF GCP UNDERLAYMENT
- D. A SECOND LAYER OF GCP UNDERLAYMENT IS INSTALLED OVER THE DRIP EDGE
- E. SEAL NON-WATER SHEDDING LAP WITH A BEAD OF ROOF CEMENT
- F. INSTALL REMAINING GCP UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
- G. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.



**EAVE OPTION-3
EXTENDED PERIMETER
FOR EXISTING CONSTRUCTION
GRACE ICE & WATER SHIELD®**

Drawing: IWSDET-103

Scale: Not to scale

Effective Date: 01/22/18

Supersedes: 05/16/06